

## CAN2

black connector 10PIN  
*pin10 CANL*



*pin8 CANH*  
black connector 10PIN

## CAN1

white connector 10PIN  
*pin3 CANH*



*pin5 CANL*  
white connector 10PIN

**Program 143 only for cars  
with DWA**