

**Program 193 only for cars
without factory alarm**

(Alternative control blinkers
- emergency light switch)
black connector 10PIN
brown pin2

(Alternative control central locking)
black connector 10PIN
yellow pin3

CAN2

black connector 10PIN
yellow pin8 CANH

blue pin10 CANL
black connector 10PIN

CAN1

white connector 10PIN
brown pin5 CANL

white pin3 CANH
white connector 10PIN

