

Information for car owner:
before using the remote "trunk open"
switch you need to disarm the alarm

CAN1

grey connector 35PIN
pink pin32 CANH

purple pin33 CANL
grey connector 35PIN

LEFT BLINKER
white connector 20PIN
red/green

RIGHT BLINKER
white connector 20PIN
blue/yellow

