

**Information for car owner:**  
before using the remote "trunk open"  
switch you need to disarm the alarm

**CAN1**

grey connector 35PIN  
**pink pin32 CANH**

**purple pin33 CANL**  
grey connector 35PIN

**LEFT BLINKER**  
white connector 20PIN  
**red/green**

**RIGHT BLINKER**  
white connector 20PIN  
**blue/yellow**

