

(blinkers sequence steering
- emergency light switch)
black connector 26PIN
brown/blue pin18

CAN1 ← or → **CAN1**

black connector 51PIN
yellow/brown pin43 CANL
yellow/red pin44 CANH
black connector 51PIN

or

black connector 54PIN
yellow/brown pin49 CANL
yellow/red pin48 CANH
black connector 54PIN

CAN2

connector 18PIN
red pin2 CANL

blue/red pin1 CANH
connector 18PIN

