

### CAN1

blue connector 36PIN

black/pink pin24 or pin6 CANH


white/pink pin25 or pin5 CANL

blue connector 36PIN

orange/black pin34

blue connector 36PIN  
(blinkers sequence steering  
- emergency light switch)

### CONTROLLER MODULE (BACK)



STARTER'S BLOCKADE CIRCUIT  
red/black pin8 black connector 24PIN  
- module on bottom of steering column

