



CAN2

diagnostic connector
orange pin6 CANH
blue pin14 CANL
diagnostic connector

CAN1

grey connector 26PIN
blue pin2 CANL
orange pin7 CANH
grey connector 26PIN

white/orange pin2
white connector 22PIN
(blinkers sequence steering
- emergency light switch)



BCM MODULE

DOOR SENSOR
white connector 16PIN
red/brown pin6