

CAN2

diagnostic connector
blue pin14 CANL



red pin6 CANH
diagnostic connector

CAN1

white connector I/P-F 32PIN
red pin14 CANH

blue pin15 CANL
white connector I/P-F 32PIN

white connector I/P-F 32PIN
(blinkers sequence steering)
green pin32



**JUNCTION BOX
(REAR)**