


(blinkers sequence steering
- emergency light switch)
blue connector 36PIN
yellow/red pin34

CAN1

blue connector 36PIN
brown/blue pin6 CANH

brown/white pin5 CANL
blue connector 36PIN



**CONTROLLER MODULE
(BACK)**

**CONTROLLER MODULE
(FRONT)**

brown near relay
(trunk servo-motor)

