

CAN1 ← or → CAN1

light blue pin32
white connector 40PIN
(blinkers sequence steering
- emergency light switch)

white connector 40PIN
pink pin21 CANL

blue pin22 CANH
white connector 40PIN

or

diagnostic connector
blue pin6 CANH

pink pin14 CANL
diagnostic connector

