

CAN1 ← or → CAN1

light blue pin33  
black connector 40PIN  
(blinkers sequence steering  
- emergency light switch)

black connector 40PIN  
blue pin22 CANL  
pink pin21 CANH  
black connector 40PIN

diagnostic connector  
blue pin6 CANH  
pink pin14 CANL  
diagnostic connector

or

+12V yellow pin1  
brown connector 12PIN1

