

CAN1 ← or → CAN1

light blue pin33

black connector 40PIN
(blinkers sequence steering
- emergency light switch)

black connector 40PIN

blue pin22 CANL

pink pin21 CANH

black connector 40PIN

diagnostic connector

blue pin6 CANH

pink pin14 CANL

diagnostic connector

or

+12V yellow pin1
brown connector 12PIN1

