

**+12V yellow pin B1 or B6**  
black connector

(blinkers sequence steering  
- emergency light switch)  
white connector 40PIN  
**blue pin26**

white connector 40PIN  
**pink pin39 CANL**

**blue pin19 CANH**  
white connector 40PIN

or

diagnostic connector  
**pink pin14 CANL**

**blue pin6 CANH**  
diagnostic connector

**CAN1** ← or → **CAN1**

