

(blinkers sequence steering
- emergency light switch)
black connector 40PIN
yellow pin33

+12V yellow pin4
black connector 8PIN

CAN1 ← or → **CAN1**

black connector 40PIN
pink pin21 CANL

blue pin22 CANH
black connector 40PIN

or

diagnostic connector
pink pin14 CANL

blue pin6 CANH
diagnostic connector

