

green/white pin26
blue connector 27PIN
(blinkers sequence steering
- emergency light switch)

CAN1 ← or → **CAN1**

do not connect

green pin22 CANH
blue connector 27PIN

or



diagnostic connector
green pin1 CANH

do not connect

CAN2

diagnostic connector
white pin14 CANL

blue pin6 CANH
diagnostic connector



+12V red/white

