CAN1

do not connect

(blinkers sequence steering - emergency light switch) black connector 42PIN green/white pin40

green pin35 CANH
black connector 42PIN
(or wire bus from driver's door)

