

CAN2

diagnostic connector
white pin14 CANL

blue pin6 CANH
diagnostic connector

CAN1 ← or → **CAN1**

do not connect

green pin1 CANH
diagnostic connector

or

black connector: 32PIN

green pin26 or pin27 CANH

do not connect

(blinkers sequence steering
- emergency light switch)
black connector 12PIN
green-white pin10

