

CAN1

black connector-12PIN (J2)
green pin4 CANL

white pin3 CANH

black connector-12PIN (J2)

CAN2

black connector-12PIN (J2)
green pin2 CANL

white pin1 CANH

black connector-12PIN (J2)

(blinkers sequence steering
- emergency light switch)
black connector-22PIN (J7)
light blue pin17

LOCK
black connector 16PIN (J4)
brown pin8

UNLOCK
black connector 16PIN (J4)
brown pin15

